

Brand	TX Model	Connector	VT500B H/506B H	VT100B	VT401HSB	VT500W	VT506W	*VT700B/VT700H(3-wire)
Lectrosonics	All "Legacy" UM and LM	TA5F	Bridge Pin 1-4 Pin2: +VDC (red) Pin3: NF (copper) Pin1:ground(green)			Bridge Pin1-4 Pin2: +VDC (red) Pin3: NF (Green) Pin4:ground (Copper)	Bridge Pin1-4 Pin2: +VDC (red) Pin3: NF (Green) Pin4:ground(Copper)	Bridge Pin 1-4 Pin2: +VDC (red) Pin3: NF (transp.) Pin4: ground (copper)
Lectrosonics	SMa, SMDa, SMQa, SMQV, LMa UM450, UM400a	TA5F	bridge pin2 to pin4 Pin1: ground(green) Pin3: +VDC(red) Pin5: NF(Copper) (Red Shrink) pin 1 to strain prong		Pin1: Ground(green) Pin2: Not Used Pin3: Audio/+VDC (copper) Pin4: Not Used Pin 5: Not Used	bridge pin2 to pin4 Pin1: ground(Copper) Pin3: +VDC(red) Pin5: NF(green) (Red Shrink) pin 1 to strain prong	bridge pin2 to pin4 Pin1: ground(Copper) Pin3: +VDC(red) Pin5: NF(Green) (Red Shrink) pin 1 to strain prong	bridge pin2 to pin4 Pin1: ground(Copper) Pin3: +VDC(red) Pin5: NF(Transp.) (Red Shrink) pin 1 to strain prong
Sennheiser	Evolution G2 Series	3.5mm TRS	Tip: +VDC(red) ring: Not Used Ground: (green) & NF(copper)			Tip: +VDC(red) ring: Not Used Ground: (Green) & (Copper)	Tip: +VDC(red) ring: Not Used Ground: (green) & NF(copper)	Tip: +VDC(red) ring: Not Used Ground: (green) & NF(copper)
Shure	L-11, SC1, LX1 U-1, T-1, UC-1 L-1, UT-1	TA4F	Pin1: Ground(green) Pin2: +VDC (red) Pin3: NF (copper) Pin4: Not Used	Pin1: Ground(copper) 1/8W 10k to Pin3 Pin2: +VDC (red) Pin3: NF (white) 1/8W 10k to Pin1 Pin4: Not Used		Pin1: Ground(Copper) Pin2: +VDC (red) Pin3: NF (Green) Pin4: Not Used	Pin1: Ground(Copper) Pin2: +VDC (red) Pin3: NF (Green) Pin4: Not Used	Pin1: Ground(copper) Pin2: +VDC (red) Pin3: NF (transp.) Pin4: ----
*Also VT800B/VT800H								

Note: White and Older Beige VT500/506 mics have the Copper and Green reversed

In VT Land

H= Beige

NF = Audio

W=White

B=Black